


Car park video / audio indicator Instruction manual




A. Function

This product is car parking distance indicator, named Guide Park Aid GPA. GPA easy to install, indicate different parking location with different "Bi, Bi" sounds and red/yellow/green LED.


- 1) LED & Audio indication for car parking;
- 2) Ultrasonic emit and reflect to test parking distance;
- 3) Low battery indication.

B. Operation


- 1) Open the battery door, then install 9V battery and close the battery door. 9V DC adaptor also including for power supply.
- 2) Install GPA on parking place properly.
- 3) Switch off GPA, park the car to your desired location. The distance of this location to GPA should not less than 1.3ft. Insure GPA's ultrasonic transducer align with car's bumper/number plate and make sure no any obstruct along.
- 4) Turn switch to ON position, the red, yellow and green LED turn on ordinal to indicate GPA calibrates parking location. When all the LED switch off means GPA completed calibration, and ready for parking test.
- 5) When drive the car 16.5 ft away to GPA, green LED will turn on with slow audio "Bi, Bi", within this section will safe to drive back slowly.
- 6) Continue to drive the car back, when 4.5 ft away to GPA, yellow LED will turn on with medium "Bi, Bi". Within that section should be caution to draw back and advert to GPA's red LED. When the red LED turn on with fast "Bi, Bi" indicate the car have park to your desired location.




A



B



C



D

IntelliSafe
MADE IN CHINA

CE

